




# Aeris



**PBJ**  
DESIGNHOUSE  
1968

**A**


10 mm



8

**B**


10 mm






8




17 mm

**1**


2




3












4



5



	<p>Please tighten the screws/legs after 4-5 weeks of use and then subsequently every 4-5 months.</p>
	<p>We do not recommend that young children are present during assembly due to the risk of choking on small parts and/or injury. Never leave your child unattended with furniture that has not been fully assembled.</p>
	<p>Requires 2 persons to lift.</p>
	<p>Do not push or drag boxes or furniture across the floor - please lift when moving.</p>
	<p>We recommend using a non-slip rug underlay.</p>
	<p>This product is for indoor use only.</p>
	<p>Do not place the furniture in direct sunlight.</p>
	<p>Do not use furniture as a climbing aid.</p>
	<p>Do not sit, stand or jump on the table</p>